

Instruction Manual

Dunking Dolphin Hoop™



INTRODUCTION

The **Dunking Dolphin Hoop™** features three balls and a fun sized pouring cup. The light up star button plays fun phrases, sing-along songs and melodies. The suction cups mount securely to a tub or bathroom wall. Make a splash with every shot!



INCLUDED IN THE PACKAGE

- Dunking Dolphin Hoop™
- 3 Balls
- · Pouring Cup
- · Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits

d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.


NOTE

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

Unlock the Packaging Locks:



- 1 Rotate the packaging locks 90 degrees counterclockwise.
- 2 Pull out the packaging locks and discard.
- Turn the packaging locks counterclockwise several times.
- 2 Pull out the packaging locks and discard.



WARNINGS:

- •Unit must be installed by an adult.
- •We do not recommend submerging the unit in the water. If the unit does get submerged in the water, please dry the unit completely before changing the battery.
- •To prevent drowning, never leave a child unattended in the bath.
- •Use a thermometer to check the temperature of the water before sitting a child in the bath. Toddlers have very sensitive skin and can burn easily if the water is too hot.
- •In case of eye contact, immediately rinse the eye with clean water.
- •Please check the suction cups periodically as they may detach after prolonged use.
- •Children should not play with the suction cups when the unit is fastened to the wall as the unit may detach and cause injuries.
- •This electronic toy is intended for use on the side of the bath and is waterproof when used as intended. Water cannot enter the electronics if the battery compartment door is locked correctly.
- •The design is verified by submerging the toy underwater to a depth of 15 cm for 30 minutes. There will be a reduction in acoustic performance when the toy is submerged in water.
- •Adult supervision needed.


AVERTISSEMENTS:

- Les piles doivent être installées par un adulte.
- Ne pas immerger le jouet. Si le jouet est immergé, éteindre le jouet, vider l'eau et le sécher avant d'ajouter le produit à bulles.
- Pour prévenir tout risque de noyade, toujours garder l'enfant sous la surveillance d'un adulte. Ne jamais laisser l'enfant seul ou avec un enfant plus âgé dans la salle de bains ou dans le bain, pas même pour un court instant ou dans un faible volume d'eau.
- Toujours vérifier la température de l'eau à l'aide d'un thermomètre avant de mettre votre enfant dans le bain. Les jeunes enfants ont la peau sensible et peuvent facilement se brûler si l'eau est trop chaude.
- Pour de meilleurs résultats, utiliser uniquement une solution à bulles de haute qualité.
- Ne pas boire le produit à bulles.
- En cas de contact avec les yeux, rincer immédiatement à l'eau claire.
- Vérifier régulièrement les ventouses car elles peuvent se détacher après une utilisation prolongée.
- Manipuler l'appareil avec précaution lorsque le réservoir est plein de produit à bulles, il peut facilement se renverser.
- Lorsque le jouet n'est pas utilisé pendant une période prolongée, l'éteindre, vider le produit à bulles du réservoir et sécher le jouet.
- Les enfants ne doivent pas jouer avec les ventouses lorsque le jouet est fixé au mur, car il pourrait se détacher et provoquer des blessures.
- Ce jouet électronique est destiné à être utilisé sur les parois d'une baignoire ou d'une douche. S'assurer que le compartiment à piles est bien fermé et que les vis sont bien serrées afin d'éviter toute infiltration d'eau.
- La conception est vérifiée en immergeant le jouet à une profondeur de 15 cm pendant 30 minutes. Les performances acoustiques diminuent lorsque le jouet est immergé.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

- 1. Make sure the unit is turned Off.
- Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
- If a used battery is present, remove the battery from the unit by pulling up on one end of the battery.



- Install 1 new AAA (AM-4/LR03) battery following the diagram inside the battery box (for best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
- 5. Replace the battery cover and tighten the screw to secure.

\triangle

WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.



ATTENTION:

Les piles ou accumulateurs doivent être installés par un adulte. Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.


RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

PRODUCT ASSEMBLY

With the VTech® Dunking Dolphin Hoop™, safety comes first. To ensure your child's safety, adult assembly is required.

 Choose a clean and dry surface in the bath where the unit can be mounted securely. Moisten each suction cup throughly, then press firmly against the wall. Once the unit is attached to the wall, test by pulling gently on the unit. The suction cups may not stick properly to textured tiles. We




recommend that the unit be removed from the wall after each use as the suction will loosen over time.

Pull the hoop up to a horizontal position. You will hear a click when the hoop is fixed in position. The hoop can be lowered again for storage.



To remove the unit from the wall, grasp the dolphin gently and pull the tab on the suction cup until it releases.



WARNING:

To reduce the risk of injuries, do not attach the VTech® Scoop & Score Dolphin any higher than a child's head height when sitting in the bath.

PRODUCT FEATURES

1. On/Off Button

To turn the unit On 0, press the On/Off Button. You will hear a song, 2 phrases and sounds. To turn the unit Off, press the On/Off Button again. The unit will shut down after playing a short melody.



2. Automatic Shut-Off

To preserve battery life, the **Scoop & Score Dolphin** will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing the light up button, the Hoop or the **On/Off** button.

NOTE

This product is in Try-Me mode in the packaging. After opening the package, please turn the unit off and on again to proceed with normal play. If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Light up Button

Press the **Light up Button** to play fun phrases and hear sing-along songs, sounds and melodies.



2. Hoop

Toss balls through the hoop, or press the **Hoop** gently to hear fun sounds. The **Hoop** will rebound automatically.



3. Pouring Play

Pour water into the dolphins spout and watch the water run through the **Hoop**.



MELODIES

- 1. Head, Shoulders, Knees and Toes
- 2. Blue Danube Waltz
- 3. Chicago
- 4. Diddle, Diddle Dumpling
- 5. I'm Forever Blowing Bubbles
- 6. Row, Row, Row Your Boat
- 7. Sailing Sailing
- 8. Sailor's Hornpipe
- 9. I Want To Go Back To Michigan, Down On The Farm
- 10. Little Robin Red Breast
- 11. Little Tommy Tucker
- 12. MacNamara's Band

SONG LYRICS

Song 1

I'm a happy dolphin who likes to play, I'm a happy dolphin who likes to play. Let's splash and have some fun!

Song 2

Think fast, you can catch it, the ball goes in the basket. Splashing fun, now you've won, time to play again!

Song 3

Wash our face and toes, face and toes, then our ears and nose, ears and nose. We are sparkly clean from head to toe.

CARE & MAINTENANCE

- 1. Remove the unit from the wall after each use.
- 2. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- 4. Make sure to dry all the elements of the unit before storing.
- Remove the batteries when the unit will not be in use for an extended period of time.
- 6. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Turn the unit Off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit sit for a few minutes, then replace the batteries.
- 4. Turn the unit **On**. The unit should now be ready to play with again.
- 5. If the unit is not working properly, install a brand new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S., 1-877-352-8697 in Canada, or by going to our website vtechkids.com and filling out our Contact Us form located under the Customer Support link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Trade Name: VTech® Model: 5680

Product Name: Dunking Dolphin Hoop™

Responsible Party: VTech Electronics North America, L.L.C.

Address: 1156 W. Shure Drive, Suite 200

Arlington Heights, IL 60004

Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

CAN ICES-003(B)/NMB-003(B)

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com vtechkids.ca

Read our complete warranty policy online at vtechkids.com/warranty vtechkids.ca/warranty

